


FRONT WALL



NOTE:
For an overview of Right side and Rear wall
See drawing no.:
ZUOK_DP_452_01_04002

For an overview of 2nd. and 3rd. pass
See drawing no.:
ZUOK_DP_452_01_04003

For details of anchors on headers and bending tubes
See drawing no.:
ZUOK_DP_452_01_04004
ZUOK_DP_452_01_04005
ZUOK_DP_452_01_04006
ZUOK_DP_452_01_04007

For details about interface between different position no.
See drawing no.:
ZUOK_DP_452_01_04008

For an overview of anchors - type and amount
See the document:
List of anchors for work shop welding

LEFT SIDE WALL

